

Installation Instructions for Ford Transit Connect FD-TC-FVK-2 Sliding Doors

Step 1- Slide drivers side sliding door to full open position. Locate sliding doors track cover retaining bolt at rear of door jam. Remove bolt, place sliding door bracket over track cover and reinstall bolt. Hand tighten bolt to hold bracket against Van panel, If bracket is not flush with Van panel remove sliding door track cover by sliding cover towards Front of Van, this gives access to Sliding door cover retaining bolt bracket. Adjust bracket tab with pliers to desired fit. Reinstall sliding door cover by sliding slots in place. Slowly close sliding door to make sure bracket has proper clearance.

Step 2- Outline where bracket contacts Van panel with grease pencil or masking tape. Remove bracket and apply paint protector.

Step 3- Reinstall sliding door bracket and tighten retaining bolt permanently. Use same process to install opposite sliding door bracket.

Step 4- Install spinner on lock and install lock on bracket- sliding door cannot pop out or slide back with lock in place. Note: Drivers side lock must be installed with keyway towards front of Vehicle for proper overhang.

See back side for rear door instructions

Watch installation video at www.slicklocks.com

Installation Instructions for Ford Transit Connect FD-TC-FVK-2 Sliding Doors

Step 1- Slide drivers side sliding door to full open position. Locate sliding doors track cover retaining bolt at rear of door jam. Remove bolt, place sliding door bracket over track cover and reinstall bolt. Hand tighten bolt to hold bracket against Van panel, If bracket is not flush with Van panel remove sliding door track cover by sliding cover towards Front of Van, this gives access to Sliding door cover retaining bolt bracket. Adjust bracket tab with pliers to desired fit. Reinstall sliding door cover by sliding slots in place. Slowly close sliding door to make sure bracket has proper clearance.

Step 2- Outline where bracket contacts Van panel with grease pencil or masking tape. Remove bracket and apply paint protector.

Step 3- Reinstall sliding door bracket and tighten retaining bolt permanently. Use same process to install opposite sliding door bracket.

Step 4- Install spinner on lock and install lock on bracket- sliding door cannot pop out or slide back with lock in place. . Note: Drivers side lock must be installed with keyway towards front of Vehicle for proper overhang.

See back side for rear door instructions

Watch installation video at www.slicklocks.com

STEP 1

Remove two bolts securing left rear door lock striker latch and discard. Hold left rear bracket PN # FD-TC2-1 REAR LEFT over mounting holes and mark weather stripping top and bottom bracket points. Carefully cut away weather stripping retaining casing between top and bottom marks. Do not cut away weather strip door gasket it will remain in place. Install bracket ON TOP OF striker latch and reinstall with bolts provided. Make sure weather stripping is secured on door edge.

STEP 2

On right rear door remove two T27 star bolts holding door latch (third bolt is not removed). Install bracket PN # FD-TC2-1 Rear Right using two Allen screws provided and hand tighten screws. Close left rear door, then close right rear door slowly making sure brackets and weather stripping clear properly, adjust right side bracket to match left side, slowly open right side door and tighten two retaining bolts, shut door and install puck lock to check alignment (always install Slick Lock NP5-10 Spinners on all puck locks).

STEP 1

Remove two bolts securing left rear door lock striker latch and discard. Hold left rear bracket PN # FD-TC2-10 REAR LEFT over mounting holes and mark weather stripping top and bottom bracket points. Carefully cut away weather stripping retaining casing between top and bottom marks. Do not cut away weather strip door gasket it will remain in place. Install bracket ON TOP OF striker latch and reinstall with bolts provided. Make sure weather stripping is secured on door edge.

STEP 2

On right rear door remove two T27 star bolts holding door latch (third bolt is not removed). Install bracket PN # FD-TC2-1 Rear Right using two Allen screws provided and hand tighten screws. Close left rear door, then close right rear door slowly making sure brackets and weather stripping clear properly, adjust right side bracket to match left side, slowly open right side door and tighten two retaining bolts, shut door and install puck lock to check alignment (always install Slick Lock NP5-10 Spinners on all puck locks).