

Installation Instructions for Nissan Sliding Door Kit

Step 1- Slide door to FULL open position- locate lock striker plate at rear of van door jam. Slider bracket mounts at rear edge of sliding door.

Step 2- Remove two T-40 star bolts- holding on striker plate, place slider bracket over mounting bolts- use grease pencil to mark where bracket lays on outside of van side panel.

Step 3- Apply larger clear tape protector directly on van surface under round end of bracket to protect paint.

Step 4- Hold bracket in place and reinstall striker plate on bracket- tighten star bolts- slowly close door and check for proper clearances.

Step 5- Close door firmly and apply small clear tape protector on sliding door edge to protect paint from lock.

Step 6- Install spinner on lock and install lock on bracket- sliding door cannot pop out or slide back with lock in place.

See back side for rear door instructions

Watch installation video at www.slicklocks.com

Installation Instructions for Nissan Sliding Door Kit

Step 1- Slide door to FULL open position- locate lock striker plate at rear of van door jam. Slider bracket mounts at rear edge of sliding door.

Step 2- Remove two T-40 star bolts- holding on striker plate, place slider bracket over mounting bolts- use grease pencil to mark where bracket lays on outside of van side panel.

Step 3- Apply larger clear tape protector directly on van surface under round end of bracket to protect paint.

Step 4- Hold bracket in place and reinstall striker plate on bracket- tighten star bolts- slowly close door and check for proper clearances.

Step 5- Close door firmly and apply small clear tape protector on sliding door edge to protect paint from lock.

Step 6- Install spinner on lock and install lock on bracket- sliding door cannot pop out or slide back with lock in place.

See back side for rear door instructions

Watch installation video at www.slicklocks.com

STEP 1

Begin by applying a spray lubricant to back side threads of bolts holding left rear lock striker plate in place. Using the T40 star socket remove striker plate. Hold Left rear bracket over two striker plate holes. Reinstall left side striker plate and bolts on top of Left rear bracket. Hold bracket firm against body of door and retighten star bit bolts.

STEP 2

Using T27 star bit socket remove two latch bolts from right rear door leave 3rd screw in place to hold latch in place. Pull weather stripping out from door and pull plastic retaining clip loose with long nose pliers. Install right rear bracket under weather stripping and reinsert retaining clip through bracket hole. Install two Allen head bolts supplied with kit. Only hand-tighten this side.

CAUTION – Slowly close left then right door making sure weather stripping clears left bracket. Once doors are closed, align lock holes with RD Pin – (dowel pin, drill bit, etc.) When you are satisfied with alignment, slowly open right side door and torque down both bolts. Shut rear door firmly.

If lock is difficult to slide on and off or difficult to close –Realign right side until desired fit is achieved – brackets can also be modified with round file or drilling center hole to accommodate various lock brands. Be careful to not damage your vehicles painted finish.

PATENT PENDING 2009

STEP 1

Begin by applying a spray lubricant to back side threads of bolts holding left rear lock striker plate in place. Using the T40 star socket remove striker plate. Hold Left rear bracket over two striker plate holes. Reinstall left side striker plate and bolts on top of Left rear bracket. Hold bracket firm against body of door and retighten star bit bolts.

STEP 2

Using T27 star bit socket remove two latch bolts from right rear door leave 3rd screw in place to hold latch in place. Pull weather stripping out from door and pull plastic retaining clip loose with long nose pliers. Install right rear bracket under weather stripping and reinsert retaining clip through bracket hole. Install two Allen head bolts supplied with kit. Only hand-tighten this side.

CAUTION – Slowly close left then right door making sure weather stripping clears left bracket. Once doors are closed, align lock holes with RD Pin – (dowel pin, drill bit, etc.) When you are satisfied with alignment, slowly open right side door and torque down both bolts. Shut rear door firmly.

If lock is difficult to slide on and off or difficult to close –Realign right side until desired fit is achieved bracket can also be modified with round file or drilling center hole to accommodate various lock brands. Be careful to not damage your vehicles painted finish.

PATENT PENDING 2009